


| Model | Nominal "JT" | Joint Opening "JT" | | | | Total Movement | Mat. Code |
|-------------------------------------------|--------------|--------------------|--------------|--------------|--------------|----------------|-----------|
| | | Seismic Min. | Thermal Min. | Thermal Max. | Seismic Max. | | |
| PDS-1100-50-2.25H | 11" | 2.5" | 10.25" | 11.75" | 16.5" | 14" | EJNB5034 |
| PDS-1100-50-2.25H w/ PF-2018F-SC-11-5.5-M | 11" | 3.5" | 10.25" | 11.75" | 16.5" | 13" | EJNB5034 |

SIGHT LINE MATCHES PDSE-1100-25-2.25H

| | | | | | |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|-------------------------|-----------------------------|
| Representative: - | Customer: - | Project: - | Location: - | Project Number: - | |
|  MM MM SYSTEMS www.mm.systems | 50 MM WAY PENDERGRASS, GA. 30567 PHONE: 706-824-7500 800-241-3460 FAX: 706-824-7501 | RIGHTS OF DESIGN All rights of design, detail, engineering and/or invention contained herein are the property of MM Systems and hereby reserved and are not to be reproduced or provided to any other party. MM Systems reserves the right to amend or withdraw any information contained herein without notice and will not be liable for any inaccuracy or ambiguity of said information. | <h1>PDS-1100-50-2.25H</h1> | | |
| | | | Drawn by: BOO | Scale: NTS | Drawing Number: EJNB5034 |
| | | | SHT. 1 OF 1 | Issue Date: 08-25-21 | |

For Spec-Data, Installation Guides, or movement requirements, contact MM Systems